



3/8" DRIVE SETS



27 PIECES—6 PT. STANDARD & DEEP METRIC SOCKET SET SET NUMBER 377

6

PART NUMBER	DESCRIPTION
-------------	-------------

6 PT. STANDARD METRIC SOCKETS	
-------------------------------	--

30-06mm	6mm
30-07mm	7mm
30-08mm	8mm
30-09mm	9mm
30-10mm	10mm
30-11mm	11mm
30-12mm	12mm

6 PT. DEEP METRIC SOCKETS	
---------------------------	--

35-10mm	10mm
35-11mm	11mm
35-12mm	12mm
35-13mm	13mm
35-14mm	14mm

ATTACHMENTS	
-------------	--

3426	Ratchet
3405	6" Extension

PART NUMBER	DESCRIPTION
-------------	-------------

6 PT. STANDARD METRIC SOCKETS	
-------------------------------	--

30-13mm	13mm
30-14mm	14mm
30-15mm	15mm
30-16mm	16mm
30-17mm	17mm
30-18mm	18mm
30-19mm	19mm

6 PT. DEEP METRIC SOCKETS	
---------------------------	--

35-15mm	15mm
35-16mm	16mm
35-17mm	17mm
35-18mm	18mm
35-19mm	19mm

ATTACHMENTS	
-------------	--

3435	Flex Handle
W316	Metal Box



19 PIECES—6 & 12 PT. STANDARD METRIC SOCKET SET SET NUMBER 364

6

12

PART NUMBER	DESCRIPTION
-------------	-------------

6 PT. STANDARD METRIC SOCKETS	
-------------------------------	--

30-06mm	6mm
---------	-----

12 PT. STANDARD METRIC SOCKETS	
--------------------------------	--

31-08mm	8mm
31-09mm	9mm
31-10mm	10mm
31-11mm	11mm
31-12mm	12mm
31-13mm	13mm

ATTACHMENTS	
-------------	--

3426	Ratchet
3403	3" Extension
3412	12" Extension

PART NUMBER	DESCRIPTION
-------------	-------------

6 PT. STANDARD METRIC SOCKETS	
-------------------------------	--

30-07mm	7mm
---------	-----

12 PT. STANDARD METRIC SOCKETS	
--------------------------------	--

31-14mm	14mm
31-15mm	15mm
31-16mm	16mm
31-17mm	17mm
31-18mm	18mm
31-19mm	19mm

ATTACHMENTS	
-------------	--

3435	Flex Handle
3475	Universal
W417	Metal Box



WARNING: WEAR
SAFETY GOGGLES USER
AND BYSTANDER



WARNING: TOOL
SAFETY INFO READ
PAGES 376-379



WARNING: COMFORT OR
PLASTIC GRIPS DO NOT PROTECT
AGAINST ELECTRIC SHOCK



WARNING: HAND
USE ONLY, NOT FOR
IMPACT USE